

# Drive Proof


Fuse Box Wiring Module (DP-210, DP-210WH, and DR200)

1. Once the power voltage is on, LED is blinking at 3times and then voltage outputs after 6 seconds.(LED is off automatically after 1 minutes.)
2. If the setting time is complete or voltage lasts 5seconds under setting voltage, the cable is off automatically
3. Please install or change the setting value on ignition off.


## HOW TO CONNECT FUSE CABLE.

RED LINE : BATT (+) : Please connect to the battery power fuse. (EX: Emergency light)  
WHITE LINE : ACC (+) : Please connect the fuse which is power on when the car ignition is on.  
BLACK LINE : GND (+) : Please earth this cable into the metal part.

### Car setting



### Hour setting



[www.DriveProof.com](http://www.DriveProof.com)

210 S. Main Street – Crestview, Florida 32536